



Service Manual

Cassette Deck

Double Cassette Deck Featuring 2 Dubbing Speed

RS-M222

(Silver Face)



This is the Service Manual for the following areas.

☐ For Asian PX.

☐ For European PX.

RS-M24 MECHANISM SERIES

Please use this manual together with the service manual for model No. RS-M222 (Original) order No. ARD82040132C8-12.

This Service Manual indicates the main differences between; RS-M222 [Original (for the ☐ mark areas)] and RS-M222 for PX.

PARTS COMPARISON TABLE:

Please revise the original parts list in the Service Manual RS-M222 (for the ☐ mark areas) to conform to the changes shown herein.

If new part numbers are shown, be sure to use them when ordering parts.

Important safety notice
Components identified by ☐ mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.

Ref. No.	Part Name & Description	Part Numbers		Remarks
		<input type="checkbox"/> ... For Asia, Latin America, Middle East and Africa areas.	<input type="checkbox"/> ... For Asian PX. <input type="checkbox"/> ... For European PX.	
G37	Tapping Screw $\oplus 4 \times 10$	XTB4 + 10BFN	_____	Deleted
G39	Washer 3 ϕ	_____	XWA3B	Added
G43	Obstruction Rod [TAPE <input type="checkbox"/>]	_____	QMR1823	Added
G44	Lock Arm	QML3649	QML3649 (TAPE <input type="checkbox"/> QML3593 (TAPE <input type="checkbox"/>)	
G57	Main Name Plate	QGS3010	QGS3035	
G61	Obstruction Rod Spring [TAPE <input type="checkbox"/>]	_____	QBT1597	Added
G65	Tapping Screw $\oplus 2 \times 6$	_____	XTN2 + 6B	Added
G66	Switch Angle	_____	QMA4224	Added
A1	Instruction Book	QQT3311	QQT3350	
A3 <input type="checkbox"/>	AC Plug Adaptor	QJP0603S	_____	Deleted
P1	Inside Carton	QPN4320	QPN4343	



* 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories.

Technics


Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

Panasonic Tokyo
Matsushita Electric Industrial Co., Ltd.
1-2, 1-chome, Shibakoen, Minato-ku, Tokyo 105 Japan


CABINET PARTS LOCATION



ELECTRICAL PARTS LOCATION (DIFFERENCE)



* For Asia, Latin America, Middle East and Africa areas.




* For PX.

Service Manual

Cassette Deck RS-M222 (Silver Face)

Double Cassette Deck Featuring 2 Dubbing Speed



This is the Service Manual for the following areas.

- ☐ For all European areas except United Kingdom.
- ☐ For United Kingdom.
- ☐ For Asia, Latin America, Middle East and Africa areas.
- ☐ For Australia.

RS-M24 MECHANISM SERIES

Specifications

Track system:	Tape deck 1: 4-track 2-channel stereo playback	Outputs:	LINE; sensitivity 60 mV, input impedance more than 47 k Ω
	Tape deck 2: 4-track 2-channel stereo recording and playback		LINE; output level 400 mV, output impedance 2.5 k Ω or less
Wow and flutter:	0.048 % (WRMS), ± 0.14 % (DIN)		HEADPHONES; output level 80 mV (8 Ω) applicable headphone impedance 8 Ω — 600 Ω
Tape speed:	4.8 cm/s	Bias frequency:	102 kHz
Frequency response:	Metal tape; 20 — 19,000 Hz 30 — 18,000 Hz (DIN)	Motor:	Electrical DC governor motor
	CrO ₂ tape; 20 — 18,000 Hz 30 — 17,000 Hz (DIN)	Heads:	Tape deck 1; 1 MX head for playback
	Normal tape; 20 — 17,000 Hz 30 — 15,000 Hz (DIN)		Tape deck 2; 1 MX head for recording and playback 1 double-gap ferrite head for erasure
Signal-to-noise ratio:	Dolby* NR in; 67 dB (above 5 kHz)	Power requirements:	AC; 110/125/220/240 V, 50-60 Hz
	Dolby NR out; 57 dB (signal level = max. input level A weighted, CrO ₂ type tape)		<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> ... Pre-set power voltage 240 V
Fast forward and rewind time:	Approx. 90 seconds with C-60 cassette tape		<input type="checkbox"/> ... Pre-set power voltage 220 V
Inputs:	MIC; sensitivity 1.0 mV, applicable microphone impedance 400 Ω — 10 k Ω	Power consumption:	15 W
		Dimensions:	43.0 cm(W) \times 11.9 cm(H) \times 27.8 cm(D)
		Weight:	5.6 kg

Specifications are subject to change without notice.

* 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories.



Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

CONTENTS

ITEM	PAGE
LOCATION OF CONTROLS AND COMPONENTS	2
OPERATING INSTRUCTION	3
DISASSEMBLY INSTRUCTION	4
MEASUREMENT AND ADJUSTMENT METHODS	6
ELECTRICAL PARTS LOCATION	10
SCHEMATIC DIAGRAM	12
CIRCUIT BOARDS	15
WIRING CONNECTION DIAGRAM	18
MECHANICAL PARTS LOCATION	21
CABINET PARTS LOCATION	23

LOCATION OF CONTROLS AND COMPONENTS



- ① Power switch [power (push on)]
- ② Cassette holder
- ③ Recording indicator [rec]
- ④ Tape indicator [auto tape select (Normal • CrO₂ • Metal)]
- ⑤ Tape counter and reset button [tape counter]
- ⑥ Input level controls [input level (■-L • ■-R)]
- ⑦ Fluorescent level meter
- ⑧ Tape ① level control [level — tape ①]
- ⑨ Cassette holder
- ⑩ Headphones jack [phones]
- ⑪ Eject button [▲ eject]
- ⑫ Record button [○ rec-□]
- ⑬ Rewind/review button [◀◀ rew/rev]
- ⑭ Fast forward/cue button [▶▶ ff/cue]
- ⑮ Playback button [▶ play-□]
- ⑯ Stop button [■ stop]
- ⑰ Pause button [⏸ pause]
- ⑱ Record-muting switch [● rec mute]
- ⑲ Dubbing speed indicator [speed] (high (red) • normal (green))
- ⑳ Dubbing/mixing indicator [dubbing]/mix]
- ㉑ Dubbing speed switch [speed (normal (■) • high (▲))]
- ㉒ Dubbing/mixing switch [dubbing/mix (off (■) • on (▲))]
- ㉓ Dolby NR switch [Dolby NR (out (■) • in (▲))]
- ㉔ Microphone jack [center mic]
- ㉕ Eject button [▲ eject]
- ㉖ Rewind button [◀◀ rew]
- ㉗ Fast forward button [▶▶ ff]
- ㉘ Playback button [▶ play-□]
- ㉙ Stop button [■ stop]
- ㉚ Pause button [⏸ pause]
- ㉛ Line output jacks [LINE OUT (R • L)]
- ㉜ Line input jacks [LINE IN (R • L)]
- ㉝ Voltage selector [VOLTAGE SELECTOR]

OPERATING INSTRUCTION

DUBBING RECORDING

- Dubbing recording can be performed at two speeds. When the Dubbing Speed Switch is set to "high," a recording of the contents of one tape onto another can be done in half the time it takes normally.
- Set the speed normally (by setting the Dubbing Speed Switch to "normal") for recording sound while you are listening to it during dubbing recording.
The tape speed during high-speed dubbing recording is double the normal speed and so the monitored sound is garbled.
- Observe the FL meter and check that the correct recording level has been set. If the level is either too low or too high, use the Tape [1] Level Control for adjustment.
The FL meter indicates the Tape [2] recording level during high-speed editing recording.

MIXING PLAYBACK AND RECORDING

- Adjust the microphone volume with the Input Level Control and the playback sound of the tape with the Level Tape [1] Control.
- Observe the FL meter during mixing recording and check that the correct recording level has been set.
- The sound from Tape [2] can also be mixed with the sound from a microphone (mic mixing). In this case, the microphone volume can be adjusted with the Input Level Control but the tape volume cannot be adjusted with the Level Tape [1] Control.

SERIES PLAYBACK

- Series playback refers to the fact that the tape in "Tape [1]" starts playing back in succession immediately after the tape in "Tape [2]" has reached the end during playback and the auto-stop mechanism has been activated or after the Stop button has been depressed and the deck set to the stop mode.
- When the Pause button of "Tape [1]" has been depressed and then the Play button is depressed, the tape in "Tape [1]" will start playing back after the tape in "Tape [2]" has finished playing back.
- If the "Tape [1]" Play and Pause buttons are depressed together with "Tape [2]" set to the recording mode, then the tape in "Tape [1]" will start to playback after the tape in "Tape [2]" has finished recording.

SYNCHRO START ("Tape [1]" ("Tape [2]"))

Synchro start is a function which allows the tapes in Tape [1] (playback) and Tape [2] (recording) to start at the same time when the recording button of Tape [2] is pushed into position with editing or mixing recording operations.

Operation:

Set the Dubbing/mixing switch to "on," push down the Pause button of Tape [1] and then push down the Play button to set the unit to the playback standby mode.

When the Record button of Tape [2] is pushed down, the Pause button of Tape [1] is automatically released. This starts the recording of Tape [2] and, simultaneously, starts the playback of Tape [1], thereby allowing edited recording.

Push down the Record Button after having checked that the Pause Button of Tape [1] has been pushed into position.

If it is not in position, the synchro start function will not work.

TROUBLESHOOTING

If operation of this unit does not seem normal, check the following points before requesting service. If the trouble cannot in this way be determined and corrected, contact the dealer from whom the unit was purchased.

- **Recordings can be made by microphone, but not from any connected sound source.**
 - Is there a microphone connected to the Center microphone jack?
 - Has the stereo amplifier been connected incorrectly?
- **No "Tape [1]" sound**
 - Has the "Tape [2]" Play button been depressed?
 - Is the Tape [1] level control at the "0" position?
- **Sound of other sources (tuner, turntable, etc.) is mixed when dubbing recording from "Tape 1" to "Tape 2".**
 - Is the Input level control set to any position other than "0"?
- **No high-speed dubbing recording**
 - Is dubbing mixing switch at OFF position?
 - Is dubbing speed switch at normal position?

DISASSEMBLY INSTRUCTION




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7




Fig. 8





Fig. 9

DISASSEMBLY PROCEDURE

Ref. No.	Procedure	To remove —	Remove —	Shown in fig. —
1	1	Case cover	• 4 screws(A)	1
2	2	Bottom cover	• 2 screws(B)	2
3	1→3	Front panel	• 2 cassette lids(C) • 7 screws(D)	1 2, 3
4	1→3→4	Sub chassis	• 8 screws(E) • 2 holders(F)	3, 4 3
5	1→2→3→4→5	Center chassis unit	• Counter belt(G) • 1 screw(H) • 1 binder(I) [D][B] ※For all European areas. • 4 connectors(J)	5 4 3 3
6	1→2→3→4→5→6	Mechanism unit [TAPE ①]	• 2 screws(K) • 1 binder(L) [D][B] ※For all European areas. • 2 connectors(M)	4 3 3
7	1→2→3→4→5→7	Mechanism unit [TAPE ②]	• 2 screws(N) • 5 connectors(O)	4 3
8	1→2→3→4→5→6→8	Operation button unit [TAPE ①]	• Cassette holder(P) • 2 screws(Q)	6 7
9	1→2→3→4→5→7→9	Operation button unit [TAPE ②]	• Cassette holder(R) • 2 screws(S)	8 9
10	1→2→3→4→5→10	FL meter circuit board	• 4 holders(T)	4

MECHANISM SECTION

1. For repair, measurement or adjustment with the mechanism removed from the unit be sure to ground the lower base plate of the mechanism.
2. For grounding, connect a extension cord to the mechanism's lower base plate and the Lug terminal from amplifier printed circuit board.
3. Without grounding, the amplifier does not operate properly.



MEASUREMENT AND ADJUSTMENT METHODS

ADJUSTMENT PARTS LOCATION




Fig. 1

NOTES: Keep good condition, set switches and controls in the following positions, unless otherwise specified

- Make sure heads are clean
- Make sure capstan and pressure roller are clean
- Judgeable room temperature: $20 \pm 5^{\circ}\text{C}$ ($68 \pm 9^{\circ}\text{F}$)
- Dolby NR switch: OUT
- Input level controls: Maximum
- TAPE [1], level control to "8"
- Dubbing/Mixing switch: OFF
- Dubbing speed switch: Normal





















ITEM	MEASUREMENT & ADJUSTMENT
A Head position adjustment [TAPE 1, TAPE 2] Condition • Playback and pause mode	<p>(The head adjusting plate is provided to adjust the tape touch of the head in cue or review mode.)</p> <ol style="list-style-type: none"> Press the playback button and pause button Measure the space between the pressure roller and the capstan <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> Standard value: $0.5 \pm 0.3\text{mm}$ </div> <ol style="list-style-type: none"> If the measured value is not within the standard value, untighten screw (A), and slide the head adjusting plate in the direction of arrow (B) for adjustment 

Fig. 2

ITEM	MEASUREMENT & ADJUSTMENT
Ⓐ Head azimuth adjustment [TAPE ①, TAPE ②] Condition: • Playback mode Equipment: • VTVM • Oscilloscope • Test tape (azimuth) ... QZZCFM	L-ch/R-ch output balance adjustment 1. Make connections as shown in fig. 3.  2. Playback the 8kHz signal from the test tape (QZZCFM). Adjust screw (B) in fig. 4 for maximum output L-ch and R-ch levels. When the output levels of L-ch and R-ch are not at maximum at the same time, readjust as follows. 3. Turn the screw shown in fig. 4 to find angles A and C (points where peak output levels for left and right channels are obtained). Then, locate the angle B between angles A and C, i.e., a point where L-ch and R-ch output levels come together at maximum. (Refer to figs. 4 and 5).  L-ch/R-ch phase adjustment 4. Make connections as shown in fig. 6. 5. Playback the 8kHz signal from the test tape (QZZCFM). Adjust screw (B) shown in fig. 4 so that pointers of the two VTVMs swing to maximum and a waveform as illustrated in fig. 7 is obtained on the oscilloscope.   
Ⓑ Tape speed [TAPE ①, TAPE ②] Condition: • Playback mode • Dubbing speed switch ... Normal/high Equipment: • Digital electronic counter or frequency counter • Test tape ... QZZCWAT	Normal speed adjustment TAPE ① 1. Make connections as shown in fig. 8. 2. Set the dubbing speed switch to Normal. 3. Play the test tape (QZZCWAT) with the TAPE ① head, and measure the playback signal frequency. If the playback signal frequency does not conform to the standard value, adjust the normal speed adjustment VR for the TAPE ① head (See fig. 1). <div style="border: 1px solid black; padding: 5px; text-align: center;"> Standard value: TAPE ① (Playback deck: Normal speed) 3010 ± 45 Hz </div> TAPE ② 4. Play the test tape (QZZCWAT) with the TAPE ② head, and measure the playback signal frequency, and then adjust the normal speed adjustment VR for the TAPE ② head so that the playback signal frequency is 15 Hz lower than the output signal frequency after adjustment of TAPE ①. High speed adjustment Note: Perform high speed adjustment about 10 seconds after the start of motor rotation. 1. Make connections as shown in fig. 8. 2. Set the dubbing/mixing switch to off, and set the dubbing speed switch to high. Short between TP7 and TP8. 3. Play the test tape (QZZCWAT) with the TAPE ① and measure the playback signal frequency. If the playback signal frequency does not conform to the standard value, adjust the high speed adjustment VR for the TAPE ① head (See fig. 1). <div style="border: 1px solid black; padding: 5px; text-align: center;"> Standard value: TAPE ① (Playback deck: Normal speed) 6020 ± 90 Hz </div> 4. Play the test tape (QZZCWAT) with the TAPE ② head, and measure the playback signal frequency, and then adjust the high speed adjustment VR for the TAPE ② head so that the playback signal frequency is 30 Hz lower than the output signal frequency after adjustment of TAPE ①. 5. After high speed adjustment, remove the short between TP7 and TP8. Tape speed fluctuation TAPE ①, TAPE ② Make measurements in same manner as above (beginning, middle and end of tape), and determine the difference between maximum and minimum values and calculate as follows: $\text{Tape speed fluctuation (Normal speed)} = \frac{f_1 - f_2}{3,000} \times 100 (\%)$ $f_1 = \text{maximum value, } f_2 = \text{minimum value}$ $\text{Tape speed fluctuation (High speed)} = \frac{f_1 - f_2}{6,000} \times 100 (\%)$ $f_1 = \text{maximum value, } f_2 = \text{minimum value}$ <div style="border: 1px solid black; padding: 5px; text-align: center;"> Standard value: Less than 1% </div> Note: Please use non metal type screwdriver when you adjust tape speed on this unit.
Ⓒ Playback frequency response [TAPE ①, TAPE ②] Condition: • Playback mode • Normal tape mode • Set TAPE ① level control to "8". Equipment: • VTVM • Oscilloscope • Test tape ... QZZCFM	Playback frequency response chart [TAPE ①, TAPE ②]  1. Test equipment connection is shown in fig. 3. 2. Place UNIT into Normal tape mode. 3. Playback the frequency response test tape (QZZCFM). 4. Measure output level at 315 Hz, 12.5 kHz, 8 kHz, 4 kHz, 1 kHz, 250 Hz, 125 Hz and 63 Hz, and compare each output level with the standard frequency 315 Hz, at LINE OUT. 5. Make measurement for both channels. 6. Make sure that the measured value is within the range specified in the frequency response chart (shown in fig. 9). Fig. 9

ITEM	MEASUREMENT & ADJUSTMENT
Ⓓ Playback gain [TAPE ①, TAPE ②] Condition: • Playback mode • Normal tape mode • Set TAPE ① level control to "8". Equipment: • VTVM • Oscilloscope • Test tape ... QZZCFM	1. Test equipment connection is shown in fig. 3. 2. Playback standard recording level at LINE OUT. 3. Make measurement for both channels. <div style="border: 1px solid black; padding: 5px; text-align: center;"> Standard value: TAPE ①, TAPE ② [0.42 V; at 8"] </div> Adjustment 1. If measured value is not within standard value, adjust VR1 (TAPE ②: L-CH), VR2 (TAPE ①: R-CH). 2. After adjustment check "Playback frequency response".
Ⓔ Erase current [TAPE ②] Condition: • Record mode • Metal tape mode Equipment: • VTVM • Oscilloscope	1. Test equipment connection is shown in fig. 3. 2. Place UNIT into Metal tape mode. 3. Press the record and pause buttons. 4. Read voltage on VTVM and calculate erase current by following formula: $\text{Erase current (A)} = \frac{\text{Voltage (V)}}{10}$ <div style="border: 1px solid black; padding: 5px; text-align: center;"> Standard value: 160 ± 10 mA </div> 5. If measured value is not within standard value, adjust VR1 (TAPE ②: L-CH), VR2 (TAPE ①: R-CH). Adjustment 1. Open the point (A) and short the point (B). (See page 15). 2. Make measurement for erase current. 3. Make sure that the measured value is within the standard value. 4. If it is beyond the value, carry out the adjustment. • If the erase current is less than 160 mA, increase the bias current. • If the erase current is more than 160 mA, decrease the bias current.
Ⓕ Overall frequency response [TAPE ②] Condition: • Record/playback mode • Normal tape mode • CrO ₂ tape mode • Metal tape mode • Input level controls ... MAX Equipment: • VTVM • AF oscillator • ATT • Oscilloscope • Resistor (600 Ω) • Test tape (reference blank tape) ... QZZCRA for Normal ... QZZCRX for CrO ₂ ... QZZCRZ for Metal	Note Before measuring and adjusting, make the playback frequency response (For the method of measurement, please refer to the playback frequency response). Overall frequency response adjustment (Recording equalizer is fixed.) 1. Make connections as shown in fig. 10. 2. Place UNIT into normal tape mode. 3. Input a 1 kHz, -24 dB signal through the LINE IN. Place the set in record mode. 4. Fine adjust the attenuator to obtain 0.4 V LINE OUT output. • Make sure that the input signal level is -24 ± 4 dB with 0.4 V output voltage. 5. Adjust the attenuator to reduce the input signal level to -24 dB. 6. Adjust the AF oscillator to generate 12.5 kHz signals, and record these signals. 7. Playback the signals recorded in step 6. (If the curve is within the charted specifications, the adjustment is complete.) If the curve is not within the charted specifications, proceed to the adjustment. Adjustment (A): When the curve exceeds the overall frequency response chart specifications (fig. 11), increase the bias current (fig. 13).  Fig. 13 1) Increase bias current by turning VR1 (L-CH) and VR402 (R-CH). (See fig. 1 on page 6.) 2) Repeat steps 6 and 7 to confirm. (Proceed to steps 8, 9 and 10 if the curve is now within the charted specifications (fig. 11).) 3) If the curve still exceeds the specifications (fig. 11), increase bias current further and repeat steps 6 and 7.

MEASUREMENT & ADJUSTMENT	
<p>ection is shown in fig. 3.</p> <p>ording level portion on test tape (QZZCFM 315Hz, 0dB), and using VTVM level at LINE OUT.</p> <p>or both channels</p> <p>TAPE [1], [2]; 0.4V ± 1dB [0.42V; at test point TP3 (L-CH) and TP4 (R-CH)]</p> <p>ot within standard, adjust VR201 (TAPE [1]: L-CH), VR202 (TAPE [1]: R-CH), VR2 (TAPE [2]: R-CH).</p> <p>ck "Playback frequency response" again.</p>	
<p>ection is shown in fig. 10.</p> <p>al tape mode.</p> <p>ause buttons</p> <p>M and calculate erase current by</p> $I = \frac{\text{Voltage across both ends of R401}}{1 (\Omega)}$ <p>160 ± 10 mA (Metal position)</p> <p>ot within standard, adjust as follows</p>	 <p>Fig. 10</p>
<p>and short the point (B) on the main circuit board in the circuit board diagram</p> <p>or erase current.</p> <p>asured value is within the erase current of 140mA to 170mA.</p> <p>ue, carry out the following adjustments:</p> <p>is less than 140mA, short the point (A).</p> <p>is more than 170mA, open the points (A) and (B).</p>	
<p>Overall frequency response chart (Normal) [TAPE [2]]</p>  <p>Fig. 11</p>	
<p>ponse adjustment by recording bias current</p>  <p>Fig. 12</p>	
<p>or to reduce the input signal level by 20dB.</p> <p>ator to generate 50Hz, 100Hz, 200Hz, 500Hz, 1kHz, 4kHz, 8kHz, 10kHz and d record these signals on the test tape.</p> <p>recorded in step 6, and check if the frequency response curve is within the limits frequency response chart for normal tapes (fig. 11).</p> <p>the charted specifications, proceed to steps 8, 9 and 10.)</p> <p>thin the charted specifications, adjust as follows:</p> <p>Adjustment (B):</p> <p>When the curve falls below the overall frequency response chart specifications (fig. 11) as shown in fig. 14.</p>  <p>Fig. 14</p>	
<p>Fig. 13</p>  <p>by turning VR401 (R-CH).</p> <p>5.)</p> <p>7 to confirm.</p> <p>9 and 10 if the curve rted specifications in</p> <p>eds the specifications s current further and</p>	<p>1) Reduce bias current by turning VR401(L-CH) and VR402 (R-CH).</p> <p>2) Repeat steps 6 and 7 to confirm. (Proceed to steps 8, 9 and 10 if the curve is now within the charted specifications in fig. 11.)</p> <p>3) If the curve still falls below the charted specifications (fig. 11), reduce bias current further and repeat steps 6 and 7.</p>

ITEM	MEASUREMENT & ADJUSTMENT
	<p>Overall frequency response chart (CrO₂, Metal) [TAPE [2]]</p>  <p>Fig. 15</p> <p>8. Place UNIT into CrO₂ tape mode.</p> <p>9. Change test tape to QZZCRX, and record 50Hz, 100Hz, 200Hz, 500Hz, 1kHz, 4kHz, 8kHz, 10kHz and 15kHz signals. Then, playback the signals and check if the curve is within the limits shown in the overall frequency response chart for CrO₂ tapes (fig. 15).</p> <p>10. Place UNIT into Metal tape mode change test tape to QZZCRZ, and record 50Hz, 100Hz, 200Hz, 500Hz, 1kHz, 4kHz, 8kHz, 10kHz, 12.5kHz and 15kHz signals. Then, playback the signals and check if the curve is within the limits shown in the overall frequency response chart for metal tapes (fig. 15).</p> <p>11. Confirm that bias currents are approximately as follows when the UNIT is set at different tape mode.</p> <p>* Read voltage on VTVM and calculate bias current by following formula:</p> $\text{Bias current (A)} = \frac{\text{Value read on VTVM (V)}}{10 (\Omega)}$ <p>around 410μA (Normal position) around 545μA (CrO₂ position) around 800μA (Metal position) } : measured at TP1 (L-CH) and TP2 (R-CH)</p>
<p>Overall gain [TAPE [2]]</p> <p>Condition:</p> <ul style="list-style-type: none"> Record/playback mode Normal tape mode Input level controls ... MAX Standard input level; <ul style="list-style-type: none"> MIC -59.5 ± 4 dB LINE IN ... -24 ± 4 dB <p>Equipment:</p> <ul style="list-style-type: none"> VTVM AF oscillator ATT Oscilloscope Resistor (600Ω) Test tape (reference blank tape) ... QZZCRA for Normal 	<p>1. Test equipment connection is shown in fig. 16.</p> <p>2. Place UNIT into Normal tape mode, and load the test tape (QZZCRA).</p> <p>3. Place UNIT into record mode.</p> <p>4. Supply 1 kHz signal (-24dB) from AF oscillator, through ATT to LINE IN.</p> <p>5. Adjust ATT until monitor level at LINE OUT becomes 0.4V.</p> <p>6. Playback recorded tape, and make sure the value at LINE OUT on VTVM becomes 0.4V.</p> <p>7. If measured value is not 0.4V, adjust VR3 (L-CH), VR4 (R-CH).</p> <p>8. Repeat from step (2).</p>  <p>Fig. 16</p>
<p>Fluorescent meter [TAPE [2]]</p> <p>Condition:</p> <ul style="list-style-type: none"> Record mode Input level controls ... MAX <p>Equipment:</p> <ul style="list-style-type: none"> VTVM AF oscillator ATT Resistor (600Ω) 	<p>1. Test equipment connection is shown in fig. 17.</p> <p>2. Short R604 by connecting a connection cord across it, as shown in fig. 17, to stop oscillation of the astable multivibrator consisting of Q601 and Q602.</p> <p>3. Supply 1 kHz signal (-24dB) to the LINE IN then press the record button.</p> <p>4. Adjust the ATT so that the output level at LINE OUT becomes 0.4V (The input level at this condition is termed the standard input level).</p> <p>5. Adjustment at "-20 dB":</p> <p>A. Adjust the ATT so that the input level is -20dB below standard recording level.</p> <p>B. Adjust VR601 so that the -20dB segment lights up in the -20 ± 0.8dB range (L-CH only) (See fig. 18).</p> <p>6. Adjustment at "0dB":</p> <p>A. Adjust the ATT so that the output level at LINE OUT becomes 0.4V (The input level at this condition is termed the standard input level.)</p> <p>B. Adjust VR602 so that the +1dB segment lights up in the 0 ± 0.2dB range of the standard input level (See fig. 19).</p> <p>7. Repeat twice between steps (5) and (6) above.</p> <p>8. Adjust ATT and check that all segments lights up when an input signal level is increased to 10dB higher than the standard input level (See fig. 20).</p>  <p>Fig. 17</p>  <p>Fig. 18</p>  <p>Fig. 19</p>  <p>Fig. 20</p>
<p>Dolby NR circuit [TAPE [2]]</p> <p>Condition:</p> <ul style="list-style-type: none"> Record mode Dolby NR switch ... IN/OUT Input level controls ... MAX <p>Equipment:</p> <ul style="list-style-type: none"> VTVM AF oscillator ATT Oscilloscope Resistor (600Ω) 	<p>1. Test equipment connection is shown in fig. 21.</p> <p>2. Place UNIT into record mode, set the Dolby NR switch to OUT position and supply to LINE IN to obtain -34.5dB at TP11 (L-CH), TP12 (R-CH) (frequency 5kHz).</p> <p>3. Confirm that the value at IN position is 8 (±2.5)dB greater than the value at OUT position of Dolby NR switch.</p>  <p>Fig. 21</p>

MEASUREMENT & ADJUSTMENT


Overall frequency response chart
(CrO₂, Metal) [TAPE 2]

Fig. 15

When the tape mode change test tape to QZZCRZ, and record 50Hz, 100Hz, 200Hz, 500Hz, 1kHz, 2kHz, 5kHz, 10kHz, 12.5kHz and 15kHz signals. Then, playback the signals and check the limits shown in the overall frequency response chart for metal tapes (fig. 15). The results are approximately as follows when the UNIT is set at different tape mode.

Measure and calculate bias current by following formula:

$$\text{Value read on VTVM (V)} \div 10 (\Omega)$$

Normal position) } : measured at TP1 (L-CH) and TP2 (R-CH)
O₂ position)
Metal position)

on is shown in fig. 16.

tape mode, and load the test

mode
4dB) from AF oscillator, through

level at LINE OUT becomes 0.4 V.
and make sure the value at LINE
OUT is 0.4 V.

0.4 V, adjust VR3 (L-CH), VR4




Fig. 16

on is shown in fig. 17.

ing a connection cord across it,
top oscillation of the astable
of Q601 and Q602.

4dB) to the LINE IN then press

the output level at LINE OUT
at level at this condition is termed

at the input level is -20dB below

level.

at the -20dB segment
±0.8dB range (L-CH)




Fig. 17

at the output level at
0.4 V.

s condition is termed
level.)

at the +1dB segment
±0.2dB range of the

See fig. 19).

steps (5) and (6) above.

at all segments lights
level is increased to

standard input level (See




Fig. 18



Fig. 19




Fig. 20

on is shown in fig. 21.

mode, set the Dolby NR switch

ply to LINE IN to obtain

(H), TP12 (R-CH) (frequency

IN position is 8 (±2.5) dB

OUT position of Dolby NR







Fig. 21

ELECTRICAL PARTS LOCATION







TAPE 2



TAPE 1



- For all European areas except United Kingdom.
 □ For United Kingdom.
 □ For Asia, Latin America, Middle East and Africa areas.
 □ For Australia.



REPLACEMENT PARTS LIST

Important safety notice
Components identified by Δ mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.

Ref No.	Part No.	Part Name & Description	Ref No.	Part No.	Part Name & Description	Ref No.	Part No.	Part Name & Description
ELECTRICAL PARTS								
E 1	QWY4122Z	Record/Playback Head	E 16	QJS1924TN	12 Pin Socket	E 34	QTW1195	Spark Killer Cover
E 2	QWY2143Z	Erase Head [TAPE 1]	E 18	QJP1921TN	3 Pin Post	[DBA]	QTW1195	[For all European areas and Australia.]
E 3	QWY2138Z	Erase Head [TAPE 2]	E 19	QJP1922TN	6 Pin Post	E 35	XSN3 + 65	Screw
E 4	QJS1921TN	3 Pin Socket	E 20	QJP1923TN	9 Pin Post	E 36	QTD1315	Cord Clamper
E 5	QJT1054	Contact	E 21	QJP1924TN	12 Pin Post	[For all European areas and Australia.]		
E 6	QJS1922TN	6 Pin Socket	E 22	QJS1962S	Socket	E 39	QTF1051	Fuse Holder
E 7	QTW1281	Insulator Sheet	E 23	QJT1041	Contact Terminal	[For Asia, Latin America, Middle East and Africa areas.]		
E 8	QTW1283	Insulator Sheet	E 24	QSF1005F	FL Meter			
E 9	XTN3 + 10B	Tapping Screw	E 25	QJT1079	Nylon Coupler			
E 10	XTN3 + 12B	Tapping Screw	E 26	QKJ0534	LED Holder			
E 11	[DBA] QTD1164	Cord Bushing	E 27	QTS1544	Microphone Shield Plate			
	[For all European areas and Australia.]		E 28	QTF1054	Fuse Holder			
E 14	[N] QTD1129	Cord Bushing	E 29	QMA4394	Volume Angle			
	[For Asia, Latin America, Middle East and Africa areas.]		E 30	XSN2 + 3	Screw @2×3			
E 15	[D] Δ SJA88	AC Power Cord	E 31	XSN26 + 5	Screw @2.6×5			
	[For all European areas except United Kingdom.]		E 32	[DBA] QTW0026	Switch Cover			
	[B] Δ RJA45YAK	AC Power Cord		[For all European areas and Australia.]				
	[For United Kingdom.]		E 33	QMA4224	Power Switch Angle			
	[A] Δ SJAG23	AC Power Cord	E 34	[N] QTW1118	Spark Killer Cover			
	[For Australia.]			[For Asia, Latin America, Middle East and Africa areas.]				

NOTES: RESISTORS

ERD...Carbon
ERG...Metal-oxide
ERS...Metal-oxide
ERO...Metal-film
ERX...Metal-film
ERQ...Fuse type metallic
ERC...Solid
ERF...Cement

CAPACITORS

ECBA...Ceramic
ECG...Ceramic
ECK...Ceramic
ECC...Ceramic
ECF...Ceramic
ECOM...Polyester film
ECQE...Polyester film
ECQP...Polypropylene

ECED...Electrolytic
ECEON...Non polar electrolytic
EQS...Polystyrene
ECS...Tantalum
QCS...Tantalum


REPLACEMENT PARTS LIST

Important safety notice
Components identified by Δ mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.

Ref No.	Part No.	Ref No.	Part No.
RESISTORS			
R 1, 2	ERD25FJ100	R 155	ERD25TJ223
R 3, 4	ERD25TJ224	R 156	ERD25TJ153
R 5, 6	ERD25FJ101	R 157	ERD25TJ473
R 7, 8	ERD25FJ680	R 158	ERD25FJ182
R 9, 10	ERD25TJ124	R 159, 160	ERD25FJ101
R 11, 12, 13, 14, 15, 16		R 161, 162, 163	
R 17, 18	ERD25FJ472	R 164	ERD25FJ103
R 19, 20	ERD25FJ560	R 165	ERD25FJ103
R 21, 22	ERD25TJ473	R 166	ERD25FJ561
R 23, 24	ERD25TJ683	R 167, 168	ERD25FJ103
R 25, 26	ERD25FJ102	R 169	ERD25TJ563
R 27, 28	ERD25TJ274	R 170	ERD25FJ103
R 29, 30	ERD25TJ105	R 171	ERD25FJ182
R 31, 32	ERD25TJ474	R 172	ERD25FJ562
R 33, 34	ERD25TJ473	R 201, 202	ERD25TJ224
R 35, 36	ERD25FJ332	R 205, 206	ERD25FJ101
R 37, 38	ERD25FJ181	R 207, 208	ERD25FJ181
R 39, 40	ERD25TJ274	R 209	ERD25FJ684
R 41, 42	ERD25TJ184	R 211, 212	ERD25TJ273
R 43	ERD25FJ151	R 213, 214	ERD25FJ392
R 44	ERD25FJ181	R 217, 218	ERD25FJ152
R 45, 46	ERD25FJ272	R 219, 220	ERD25FJ821
R 47, 48, 49, 50		R 221, 222	ERD25FJ472
R 51, 52	ERD25FJ822	R 223, 224	ERD25TJ224
R 53, 54	ERD25FJ820	R 225, 226	ERD25FJ272
R 55, 56	ERD25FJ123	R 227, 228	ERD25TJ224
R 57, 58	ERD25FJ102	R 229, 230	ERD25FJ272
R 59, 60	ERD25FJ392	R 231, 232	ERD25TJ473
R 61, 62	ERD25FJ152	R 233	ERD25FJ472
R 63, 64	ERD25TJ104	R 234	ERD25FJ103
R 65, 66		R 235, 236	ERD25TJ563
R 67, 68		R 301, 302	ERD25TJ223
R 69, 70	ERD25TJ393	R 303, 304	ERD25TJ474
R 71, 72	ERD25TJ154	R 305, 306	ERD25FJ102
R 73, 74	ERD25FJ102	R 307, 308	ERD25FJ103
R 75 [DB]	ERG12ANJ270	R 309, 310	ERD25TJ393
[For all European areas.]		R 311, 312	ERD25FJ472
[AN] ERD25FJ270		R 313, 314	ERD25TJ473
[For Australia, Asia, Latin America, Middle East and Africa areas.]		R 315	ERD25FJ472
R 76 [DB]	ERG2ANJ560	R 316	ERD25FJ103
[For all European areas.]		R 317	ERD25TJ223
[AN] ERD25FJ560		R 319	ERD25TJ105
[For Australia, Asia, Latin America, Middle East and Africa areas.]		R 320	ERD25TJ154
R 77, 78	ERD25FJ152	R 321	ERD25FJ332
R 79, 80	ERD25TJ474	R 322	ERD25FJ221
R 81, 82	ERD25FJ151	R 323	ERD25FJ471
R 83, 84	ERD25FJ103	R 324	ERD25FJ150
R 85, 86	ERD25TJ563	R 325	ERD25FJ221
R 87, 88		R 326	ERD25FJ562
[DB] ERD25TJ333		R 327	ERD25TJ563
[For all European areas.]		R 328	ERD25TJ563
R 101	ERD25FJ103	R 329, 330, 331	
R 102, 103	ERD25FJ472	R 332, 333	ERD25FJ103
R 105, 106	ERD25FJ103	R 334	ERD25TJ563
R 108	ERD25FJ102	R 401	ERD25FJ180
R 111, 112	ERD25FJ103	R 402	ERD25FJ100
R 113	ERD25TJ563	R 403, 404	ERD25FJ562
R 113	ERD25FJ562	R 405	ERD25FJ100
R 114	ERD25TJ563	R 406	ERD25FJ821
R 116	ERD25FJ562	R 407, 408	
R 117 [DB]	ERD25TJ104	R 407, 408	ERG2ANJ101
[For all European areas.]		[For all European areas.]	
R 118	ERD25FJ103	[AN] ERD25FJ101	
R 119, 120	ERD25FJ472	[For Australia, Asia, Latin America, Middle East and Africa areas.]	
R 121, 122	ERD25FJ103	R 410	ERD25FJ821
R 123	ERD25FJ102	R 411	ERD25FJ681
R 124 [DB]	ERD25TJ563	R 412	ERD25FJ152
[For all European areas.]		R 413	ERD25FJ182
[AN] ERD25FJ562		R 414	ERD25FJ222
[For Australia, Asia, Latin America, Middle East and Africa areas.]		R 415	ERD25FJ272
R 125 [DB]	ERD25TJ563	R 501, 502, 503	
[For all European areas.]		R 504	ERD25TJ684
[AN] ERD25FJ562		R 601	ERD25TJ684
[For Australia, Asia, Latin America, Middle East and Africa areas.]		R 602	ERD25FJ471
R 126	ERD25TJ273	R 603	ERD25FJ472
R 128	ERD25FJ562	R 604	ERD25FJ182
R 129		R 605, 606	ERD25TJ105
R 130 [DB]	ERD25TJ104	R 607, 608	ERD25FJ102
[For all European areas.]		R 609 [DB]	ERG1ANJ221
[AN] ERD25FJ103		[For all European areas.]	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		[AN] ERD25FJ181	
R 131, 132	ERD25FJ472	[For Australia, Asia, Latin America, Middle East and Africa areas.]	
R 133, 134	ERD25FJ103	R 610, 611, 612	
R 135	ERD25FJ102	R 612	ERD25FJ682
R 136	ERD25FJ152	R 615	ERD25TJ393
R 137	ERD25TJ104	R 616	ERD25TJ563
R 138	ERD25TJ683	R 617, 618	
R 139	ERD25TJ104	[DB] ERD25FJ271	
R 140	ERD25TJ223	[For all European areas.]	
R 141	ERD25TJ104	[AN] ERD25FJ181	
R 142, 143	ERD25FJ103	[For Australia, Asia, Latin America, Middle East and Africa areas.]	
R 145, 146	ERD25TJ563	R 619	ERD25FJ103
R 147	ERD25FJ103	R 620	ERD25TJ683
R 148	ERD25TJ223	R 701 [DB]	Δ ERQ12HJ5R6
R 149	ERD25FJ472	[For all European areas.]	
R 150	ERD25FJ562	[AN] Δ ERD25FJ3R9	
R 151	ERD25FJ472	[For Australia, Asia, Latin America, Middle East and Africa areas.]	
R 152	ERD25FJ272	R 702 [DB]	Δ ERQ12HJ5R6
R 153	ERD25FJ103	[For all European areas.]	
R 154	ERD25FJ272	[AN] Δ ERD25FJ3R9	
		[For Australia, Asia, Latin America, Middle East and Africa areas.]	


Ref No.	Part No.	Ref No.	Part No.
VARIABLE CAPACITORS			
VR 1, 2	EVNM4AA00B24	D 135	SM112
VR 3, 4	EVNM4AA00B54	D 136, 137	MA161
VR 201, 202	EVNM4AA00B24	D 138	QVD1SS141T
VR 203, 204	QVBG1LU10A24	D 301, 302, 304, 305, 306, 307	MA161
VR 301, 302	QVAG1AU10A24	D 308	SPB26MUW
VR 401	EVNM4AA00B	D 309	SLB26GG4
VR 402	EVNM4AA00B54	D 401, 402, 403, 404	QVDLS004EM
VR 601	EVNM4AA00B14	D 405, 406, 601, 602, 603, 604, 605, 606	MA161
VR 602	EVNM4AA00B24	D 607	MA1039
CAPACITORS			
C 1, 2	ECKD1H331KB	D 701	MA1220M
C 3, 4	ECEA1AS101	D 702, 703, 704, 705, 706, 707, 708, 709, 710	Δ SM112
C 7, 8	ECQM1H273JZ	INTEGRATED CIRCUITS	
C 9, 10	ECFDD153KXY	IC 2	AN6552
C 11, 12	ECDD1H090DC	IC 3, 4	NE646N
C 15, 16	ECCD1H090DC	IC 5	NJM4556D
C 17, 18	ECEA502R33	IC 6	AN6552
C 19, 20	ECEA1HS100	IC 201	MS219L
C 21, 22	ECFDD392KXY	IC 401	AN6256
C 23, 24	ECQM1H472JZ	IC 501	BA336
C 25, 26	ECQM1H273JZ	IC 601	AN6870N
C 27, 28	ECEA1HS100	MULTIPLEX FILTERS	
C 29, 30	ECQM1H562JZ	MPX 1, 2	QLM9Z9K
C 31, 32	ECEA50MR3R3	TRANSISTORS	
C 33, 34	ECQM1H104JZ	Q 1, 2, 3, 4, 5, 6, 9, 10, 11, 12, 13, 14	2SD636
C 35, 36	ECEA1HS100	Q102, 103, 104, 105	2SD636
C 37, 38	ECFDD473KXY	Q 106	2SB641
C 39, 40	ECEA1HS100	Q 107	2SB641
C 41	ECEA1AS331	Q 108	2SD636
C 42	ECEA0JS102	Q 109	2SB641
C 43, 44	ECEA502R33	Q 110	2SD636
C 45, 46	ECCD1H221K	Q 111	2SB641
C 49, 50	ECQM1H183JZ	Q 112, 112	2SD636
C 51, 52	ECQM1H272JZ	Q 113	2SB641
C 53, 54	ECQM1H103JZ	Q 114	2SD636
C 55, 56	ECQM1H822JZ	Q 115	2SD946
C 57, 58, 59, 60	ECFDD223KXY	Q 201, 202, 203, 204, 205, 206, 207, 208, 209, 210, 211	2SB641
C 61, 62	ECKD2H121KB	Q 301, 302, 303, 304, 305, 306	2SD636
C 63, 64	ECEA1HN010	Q 307	2SB641
C 65, 66	ECEA5021	Q 401	2SD592
C 71, 72	ECEA502AR7	Q 402 [DB]	2SD592
C 73, 74	ECKD1H102MD	[For all European areas.]	
C 75, 76	ECEA502R2	[AN] 2SD638	
C 77, 78	ECKD1H391KB	[For Australia, Asia, Latin America, Middle East and Africa areas.]	
C 79, 80	ECKD1H561KB	Q 501	2SD636
C 101	ECEA1HS100	Q 601	2SB641
C 102, 103	ECEA1ES220	Q 602, 603	2SD636
C 104	ECEA1AS470	Q 701	2SD1265
C 105	ECEA1ES220	Q 702	2SB941
C 106	ECEA502AR7	Q 703	2SD965
C 107	ECEA1ES101	NOTES:	
C 108, 109	ECEA502R33	• S1-1—S1-12.....Record/playback select switch (shown in playback position).	
C 110 [DB]	ECEA502R2	①...Playback, ②...Record	
[For all European areas.]		• S2-1—S2-4Dolby NR IN/OUT select switch (shown in OUT position).	
[AN] ECEA1ES220		①...Dolby OUT, ②...Dolby IN	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		• S3-1—S3-6Dubbing/Mixing switch (shown in OFF position).	
R 110 [DB]	ERG2ANJ270	①...OFF, ②...ON	
R 111 [DB]	ERG2ANJ101	• S4-1, S4-2.....Dubbing speed switch (shown in Normal: 4.8cm/s).	
[For all European areas.]		①...NORMAL, ②...HIGH	
[AN] ERD25FJ101		• S5-1Record muting switch (shown in OFF position).	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		• S6.....TAPE ② (Record/Playback deck): playback switch (shown in stop mode).	
R 112 [DB]	ERG2ANJ270	• S7.....TAPE ② (Record/Playback deck): FF/Rewind switch (shown in stop mode).	
[For all European areas.]		• S8.....TAPE ② (Playback deck): playback switch (shown in stop mode).	
[AN] ERD25FJ562		• S9.....TAPE ① (Playback deck): FF/Rewind switch (shown in stop mode).	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		• S10.....TAPE ① (Playback deck): playback EQ select switch (shown in 70μs mode).	
R 113 [DB]	ERG2ANJ270	• S11.....TAPE ① (Playback deck): pause switch (shown in OFF position).	
[For all European areas.]		• S12.....TAPE ② (Record/Playback deck): auto tape select switch (For Metal tape).	
[AN] ERD25FJ102		• S13.....TAPE ② (Record/Playback deck): auto tape select switch (For CrO ₂ tape).	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		• S14.....TAPE ① (Playback deck) Motor switch.	
R 114 [DB]	ERG2ANJ270	• S15.....TAPE ② (Record/Playback deck) Motor switch.	
[For all European areas.]		• S16.....Power ON/OFF switch (shown in OFF position).	
[AN] ERD25FJ102		• S17.....AC power voltage select switch.	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		• VR1, 2TAPE ② (Record/Playback deck): playback gain adjustment VR.	
R 115 [DB]	ERG2ANJ270	• VR3, 4TAPE ② (Record/Playback deck): recording gain adjustment VR.	
[For all European areas.]		• VR201, 202TAPE ① (Playback deck): playback gain adjustment VR.	
[AN] ERD25FJ102		• VR203, 204TAPE ① (Playback deck): output level/dubbing level controls.	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		• VR301, 302TAPE ② (Record/Playback deck): input level controls.	
R 116 [DB]	ERG2ANJ270	• VR401, 402Recording bias current adjustment VR.	
[For all European areas.]		• VR601FL meter adjustment VR (for -20dB indication).	
[AN] ERD25FJ102		• VR602FL meter adjustment VR (for 0dB indication).	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		• VR01Tape speed adjustment VR (for NORMAL speed).	
R 117 [DB]	ERG2ANJ270	• VR02Tape speed adjustment VR (for HIGH speed).	
[For all European areas.]		• L1, 2, 5Peaking coil.	
[AN] ERD25FJ102		• L3, 4Trap coil.	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		• L401Bias oscillation coil.	
R 118 [DB]	ERG2ANJ270	• MPX1, 2M.P.X coil.	
[For all European areas.]		• Resistance are in ohms (Ω), 1/4 watt unless specified otherwise.	
[AN] ERD25FJ102		• Capacity are in microfarads (μF) unless specified otherwise.	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		• All voltage values shown in circuitry are under no signal condition and volume control at minimum position.	
R 119 [DB]	ERG2ANJ270	However, the voltage in record mode is indicated in () when it differs from that in playback mode.	
[For all European areas.]		TAPE ① PLAYVoltage at playback mode (TAPE ①)	
[AN] ERD25FJ102		TAPE ① NormalVoltage Normal tape mode (TAPE ①)	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		Dubbing speed high tape MetalVoltage at Dubbing speed high, Metal tape mode.	
R 120 [DB]	ERG2ANJ270	PLAY DUBBING/MIXING SW ONVoltage at playback, dubbing/mixing on mode.	
[For all European areas.]		CUE/REVIEWVoltage at CUE/REVIEW mode.	
[AN] ERD25FJ102		Dubbing speed highVoltage at Dubbing speed high mode.	
[For Australia, Asia, Latin America, Middle East and Africa areas.]		STOPVoltage at STOP mode.	
R 121 [DB]	ERG2ANJ270	TAPE ① PAUSEVoltage at Pause mode (TAPE ①).	
[For all European areas.]		MIC INVoltage at MIC IN mode (Auto INPUT selector).	
[AN] ERD25FJ102		For measurement use VTVM.	

SCHEMATIC DIAGRAM



- The mark (▼) shows test point e.g. ▼ = Test point 1.
- () indicates + B (bias).
- () indicates B- (bias).
- () indicates the flow of the playback signal [TAPE ②]
- () indicates the flow of the recording signal [TAPE ②]
- () indicates the flow of the playback signal [TAPE ①]
- () indicates the flow of the playback signal [TAPE ①]
- Described in the schematic diagram are two types of number production parts number for transistors and diodes. One type of number is used for supply parts number and production parts number.

ATIC DIAGRAM




▼ = Test point 1.

Playback signal [TAPE 2].
Recording signal [TAPE 2].
Playback signal [TAPE 1].
Playback signal [TAPE 1]. (Dubbing/Mixing switch: ON).
There are two types of numbers; the supply parts number and the production parts number.
Supply parts number and production parts number when they

e.g. Q701
2SC1265(O,P) — Production parts number
[2SC1265] — Supply parts number
D405, 406
QVD1S2473T — Production parts number
[MA161] — Supply parts number

- For all European areas, except United Kingdom.
- For United Kingdom.
- For Asia, Latin America, Middle East and Africa areas.
- For Australia.

This schematic diagram may be modified at any time with the development of new technology.




For Asia, Latin America, Middle East and Africa areas.

Playback S/N ratio Test tape..... QZZCFM	Greater than 45dB
Overall distortion Test tape ... QZZCRA for Normal ... QZZCRX for CrO ₂ ... QZZCRZ for Metal	Less than 4%
Overall S/N ratio Test tape..... QZZCRA	Greater than 43dB (without NAB filter)

CIRCUIT BOARDS

MAIN CIRCUIT BOARD




FL METER CIRCUIT BOARD


IC601 AN6870N

1	-10.9V
2	-8.5V
3	10.3V
4	0.5V
5	0.5V
6-23	-10.8V
24	-6.2V
25	6.3V
26	-8.4V
27	-9.1V
28	-9.1V

Q603 2SD636

E	-10.7V
C	0V
B	-10.9V

MOTOR GOVERNOR CIRCUIT BOARD
(TAPE 1)



FL METER CIRCUIT BOARD

IC601 AN6870N

1	-10.9V
2	-8.5V
3	10.3V
4	0.5V
5	0.5V
6-23	-10.8V
24	-6.2V Stop 時 -11V
25	6.3V
26	-8.4V
27	-9.1V
28	-9.1V

Q603 2SD636


E	-10.7V Stop 時 -10.4V
C	0V Stop 時 -10.4V
B	-10.9V Stop 時 -9.7V

Q601 2SB641

E	— Stop 時 -10.3V
C	-10.4V Stop 時 -10.3V
B	-6.3V Stop 時 -10.9V

Q602 2SD636

E	-11V Stop 時 -11V
C	-6.3V Stop 時 -10.9V
B	-10.4V Stop 時 -10.3V


MOTOR GOVERNOR CIRCUIT BOARD
(TAPE 1, TAPE 2)

NOTES:



- The circuit shown in this diagram on the conductor side indicates printed circuit on the back side of the printed circuit board.
- Voltage values indicated in this diagram are under no signal condition and playback mode with volume control at minimum position otherwise specified.
- () Voltage at record mode.
- TAPE 1 PLAY Voltage at playback mode (TAPE 1).
- TAPE 1 Normal Voltage at Normal tape mode (TAPE 1).
- Dubbing speed high tape Metal Voltage at Dubbing speed high, Metal tape mode.
- PLAY DUBBING/MIXING SW ON Voltage at playback, dubbing/mixing on mode.
- CUE/REVIEW Voltage at CUE/REVIEW mode.
- Dubbing speed high Voltage at Dubbing speed high mode.
- STOP Voltage at STOP mode.
- TAPE 1 PAUSE Voltage at Pause mode (TAPE 1).
- MIC IN Voltage at MIC IN mode (Auto INPUT selector).
- For measurement use VTVM.
- [D] For all European areas, except United Kingdom.
- [B] For United Kingdom.
- [N] For Asia, Latin America, Middle East and Africa areas.
- [A] For Australia.

This circuit board diagram may be modified at any time with the development of new technology.


TERMINATIONS



WIRING CONNECTION DIAGRAM




[N] * For Asia, Latin America Middle East and Africa areas.



A * For Australia.

NOTES:

BLKBlack
BLUBlue
BRNBrown
GRYGray
GRN ...Green
L. BLU ...Light Blue
NILNo Color Mark
ORG ...Orange
PNKPink
REDRed
SLDShield Wire
VLTViolet
WHT..... White
YELYellow



NOTES:


BLKBlack
BLUBlue
BRNBrown
GRYGray
GRN ...Green
L. BLULight Blue
NILNo Color Mark
ORG ...Orange
PNKPink
REDRed
SLDShield Wire
VLTViolet
WHTWhite
YELYellow

REPLACEMENT PARTS LIST

Ref No.	Part No.	Part Name & Description	Ref No.	Part No.	Part Name & Description
MECHANICAL PARTS			M 68	QMR1820	Record Rod
M 1	QBP1874	Cassette Pressure Spring	M 69	QMR1824	Control Rod
M 2	QDR1139	Reel Table	M 70	QNZ1239	Flywheel Thrust Retainer
M 3	QMB1336	Supply Reel Table Hub	M 71	QBS1128	Lock Pin
M 5	QML3586	Music Select Lever	M 72	QML3582	Pause Lock Lever
M 6	QML3594	Auto Stop Release Arm	M 73	QXA1178	Plunger Angle [TAPE□]
M 7	QML3603	Erase Safety Lever	M 73	QMA4063	Flywheel Retainer [TAPE□]
M 8	QML3604	Auto Stop Driving Lever	M 74	QMZ1254	Wire Clamper
M 9	QML3605	Auto Stop Detection Lever	M 76	QXF0164	Flywheel Assembly
M 10	QML3592	Change Lever	M 77	QZK0241	Takeup Gear Assembly
M 11	QMR1821	Auto Stop Connection Rod	M 78	QXU0290	Motor Assembly
M 12	QMR1822	Eject Rod	M 79	QXK2286	Sub Chassis Assen.bly
M 13	QXL1355	Main Lever Assembly	M 80	QDG1199	Auto Stop Gear
M 14	QXL1354	Sub Lever Assembly	M 81	QDG1200	Cam Gear
M 15	QXL1381	Pressure Roller Lever	M 83	QDB0316	Capstan Belt
M 16	QML3588	Fast Forward Lever	M 84	QDB0290	Fast Forward Belt
M 17	QXD1143	Takeup Reel Table Assembly	M 85	QDB0274	Takeup Belt
M 18	QXL1382	Idler Lever Assembly	M 86	QXL1360	Record/Playback Change Arm Assembly
M 19	QXI0111	Takeup Idler Assembly	M 87	QML3580	Record/Playback Change Lever
M 20	QXL1383	Fast Forward Arm Assembly	M 88	QXP0607	Fast Forward Connection Pulley Assembly
M 21	QXI0112	Rewind Idler Assembly	M 90	XTN3 + 10B	Tapping Screw $\phi 3 \times 10$
M 22	QXI0113	Fast Forward Idler Assembly	M 91	XTN3 + 24B	Tapping Screw $\phi 3 \times 24$
M 23	QMK1840	Head Base Plate	M 92	XSN26 + 3	Screw $\phi 2.6 \times 3$
M 24	QMZ1241	Head Spacer	M 93	QBW2049	Washer
M 27	QMK1838	Supper Base Plate	M 94	QBW2026	Washer
M 28	QML3591	Brake Arm	M 95	QBW2008	Washer 2ø
M 29	QMZ1240	Sub Head Base Plate	M 96	QBW2012	Poly Washer
M 30	QMN2550	Roller	M 97	XUB3FT	Stop Ring 3ø
M 31	QDK1057	Steel Ball	M 98	XUB4FT	Stop Ring 4ø
M 32	QBP1873	Head Base Plate Pressure Spring	M 99	QBN1744	Sub Gear Spring
M 33	QMA3858	Head Adjustment Plate	M 100	QBN1745	Main Gear Spring
M 34	QDP1828	Fast Forward Pulley	M 101	QBC1357	Lock Pin Pressure Spring
M 35	QDB0235	Belt	M 102	QBN1739	Change Lever Spring
M 36	QMA4437	Angle	M 103	QBT1896	Lever Release Spring
M 38	QXH0369	Chassis Cover	M 104	QBT1895	Spring R/P Change Arm Spring
M 39	QMF2118	Lock Plate	M 105	QMC0136	Spacer [TAPE□]
M 40	XTN26 + 6B	Tapping Screw $\phi 2.6 \times 6$	M 105	QML3644	Tape Detection Lever-A (for Metal Tape) [TAPE□]
M 41	XTN26 + 10B	Tapping Screw $\phi 2.6 \times 10$	M 106	QML3645	Tape Detection Lever-B (for CrO ₂)
M 42	XTN26 + 12B	Tapping Screw $\phi 2.6 \times 12$	M 107	QWA4228	Detection Lever Angle-B
M 43	XSN2 + 10	Screw $\phi 2 \times 10$	M 108	QMS2546	Detection Lever Shaft
M 44	XTN26 + 6BFZ	Tapping Screw $\phi 2.6 \times 6$	M 109	XSN2 + 5	Screw $\phi 2 \times 5$
M 46	QBW2012	Washer	M 111	XTN2 + 10B	Tapping Screw $\phi 2 \times 10$
M 47	QBW2008	Poly Washer 2ø	M 112	QMA4392	Circuit Board Angle
M 48	QBC1372	Reel Table Spring	M 113	QME0157	Plunger
M 49	QBT1682	Auto Stop Connection Rod Spring	M 114	QME0163	Plunger
M 50	QBN1746	Auto Stop Lever Spring	M 115	QBC1358	Plunger Release Spring
M 51	QBN1741	Change Lever Spring	M 116	QML3616	Lock Release Lever
M 52	QBN1747	Connection Spring	M 117	QML3801	Pause Release Lever
M 53	QBT1894	Main Lever Spring	M 118	QML3802	Pause Connection Lever
M 54	QBN1742	Pressure Roller Release Spring	M 120	XUC3FT	Stop Ring 3ø
M 55	QBN1743	Pressure Roller Spring	M 121	XSN3 + 6S	Screw $\phi 3 \times 6$
M 56	QBN1748	Fast Forward Spring	M 122	XWA3B	Washer 3ø
M 57	QBT1893	Idler Spring	M 123	XSN26 + 8	Screw $\phi 2.6 \times 8$
M 58	QBN1740	Spring	M 124	QBW2085	Washer
M 59	QBC1278	Head Spring			
M 60	QBCA0008	Head Spring			
M 61	QBT1597	Brake Arm Spring			
M 62	QBT1892	Head Release Spring			
M 63	QDG1201	Main Gear			
M 64	QDG1202	Sub Gear			
M 65	QML3581	Sub Control Lever			
M 66	QML3583	Main Control Lever			
M 67	QML3584	Reverse Lever			

MECHANICAL PARTS LOCATION

(FRONT SIDE)




- When servicing this mechanism unit, refer to the disassembly notes and assembly instructions described in the service manuals of RS-M51, RS-M13, RS-M14 and RS-M04 (RS-M24 mechanism series).
- Components identified by TAPE 1 in the mechanism parts location diagram are used only for mechanisms loaded with TAPE 1 (Playback deck), while components identified by TAPE 2 are used only for mechanisms loaded with TAPE 2 (Record/playback deck). Components without tape identification are common to both mechanisms.


SPECIFICATIONS

Pressure of pressure roller	350 ± 50 g
Takeup tension • Use cassette torque meter ... QZZSRKCT	45 + 15 - 10 g·cm
Wow and flutter: (JIS) • Use test tape ... QZZCWAT	Less than 0.06% (WRMS)

(REAR SIDE)



CABINET PARTS LOCATION



REPLACEMENT PARTS LIST

Ref No.	Part No.	Part Name & Description	Ref No.	Part No.	Part Name & Description	Ref No.	Part No.	Part Name & Description	Ref No.	Part No.	Part Name & Description	
CABINET PARTS			G 20	QYB0417	Chassis Plate	G 49	QML3601	Record Lever [Tape 1]	G 63	QMF2253	Angle	
G 1	QYP1082	Front Panel	G 21	QXC0080	Counter A'ssy		QXL1494	Record Button Assembly	G 64	XSN3 + 6	Screw 3x6	
G 1-1	QGL1176	Meter Filter	G 22	QYK0139	Volume Knob-A	G 50	QXL1495	[Tape 2]	ACCESSORIES			
G 2	QYF0539	Cassette Lid-A	G 23	QYK0140	Volume Knob-B	G 51	QXL1496	Rewind Button Assembly	A 1 [D]	QQT3286	Instruction Book	
G 3	QYF0540	Cassette Lid-B	G 24	QYG1592	Dial Scale			Fast Forward Button	[For all European areas except United Kingdom.]	[N]	QQT3311	Instruction Book
G 4	QGC1216W	Case Cover	G 25	QBJ2088	Connection Pulley	G 52	QXL1497	Assembly	[For Asia, Latin America, Middle East and Africa areas.]	[BA]	QQT3287	Instruction Book
G 5	QKA1084	Rubber Foot	G 26	QBW2008	Washer			Playback Button	[For United Kingdom and Australia.]	A 2	QEB0125	Connection Cord
G 6	QGC1217	Bottom Cover	G 27	QGG0202	Slide Guide	G 53	QXL1498	Assembly		A 3 [N] Δ	QJP0603S	AC Plug Adaptor
G 7	QKA1083	Rubber Foot	G 29	XTB4 + 10GFN	Screw 4x10	G 54	QXL1499	Stop Button Assembly	[For Asia, Latin America, Middle East and Africa areas.]			
G 8	QHQ1313	Screw	G 30	XTV3 + 10BFN	Screw 3x10	G 55	QMH2090	Pause Button Assembly	PACKINGS			
G 9	QKM1542W	Main Chassis	G 31	XTB4 + 14BFZ	Tapping Screw 4x14	G 56	XTN26 + 6BFZ	Cassette Holder	P 1	QPN4320	Inside Carton	
			G 32	QNQ1070	Nut	G 57 [D]	QGS3008	Tapping Screw 2.6x6	P 2	QPA0670	Cushion-A	
G 10	QGO1881B	Push Button	G 33	XTN26 + 8BFZ	Tapping Screw 2.6x8	[For all European areas except United Kingdom.]		Main Name Plate	P 3	QPA0671	Cushion-B	
G 11	QGO1881S	Push Button	G 34	XSN3 + 6S	Screw 3x6	[N]	QGS3010		P 4	QPS0434	Pad	
G 12	QGO2032	Push Button	G 35	XTS3 + 6B	Screw 3x6	[For Asia, Latin America, Middle East and Africa areas.]			P 5	XZB50X65A02	Poly Sheet	
G 13	QMA4223	Angle	G 36	XTV3 + 12BFN	Tapping Screw 3x12	[BA]	QGS3009	Main Name Plate	P 6	QPC0072	Poly Sheet	
G 14	QMR1922	Rod (Power Switch)	G 37	XTB4 + 10BFN	Tapping Screw 4x10	[For United Kingdom and Australia.]						
G 15	QMR1921	Rod	G 41	QXA1044	Operation Button Angle Assembly	G 58	XUB5FT	Stop Ring				
G 16	QML3788	Record Lever	G 42	QBP1875	Operation Lever Spring	G 59	QBW2082	Snap Washer				
G 17	QBS1135	Spring Record Wire	G 44	QML3649	Lock Arm-B	G 60	QBN7010	Spring				
G 18	QJC0040	Earth Plate-A	G 45	QDG1102	Holder Gear	G 62	QBP1923	Spring				
G 19	QJC0041	Earth Plate-B	G 47	QMN2554	Operation Lever Shaft							
			G 48	QXL1493	Eject Button Assembly							

Service Manual

Supplement

Double Cassette Deck
Featuring 2 Dubbing Speed












Cassette Deck







RS-M222

(Silver Face)
(Black Face)

RS-M24 MECHANISM SERIES

- For     mark areas, use this manual together with the service manual for model No. RS-M222 (Original) order No. ARD82040132C8-12 and RS-M222 (Supplement-1) order No. ARD82100132S8-01.
- For   mark areas, use this manual together with the service manual for model No. RS-M222 [Original (for  mark areas)] order No. ARD82040132C8-12 and RS-M222 (for   mark areas) order No. ARD82060157A4-01.


This is the Service Manual for the following areas.





-  ...For all European areas except United Kingdom.
-  ...For United Kingdom.
-  ...For Asia, Latin America, Middle East and Africa areas.
-  ...For Australia.
-  ...For Asian PX.
-  ...For European PX.

PARTS COMPARISON TABLE:


Please revise the original parts list in the Service Manual (RS-222) to conform to the changes shown herein.

If new part numbers are shown, be sure to use them when ordering parts.

Important safety notice
Components identified by  mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.


Ref. No.	Part Name & Description	Part Numbers		Remarks
		Former Type	New Type	
E25    	Nylon Coupler	QJT1079	QJT1096	
* For PX, Asia, Latin America, Middle East and Africa areas.				
M125	Protection Angle (for Flywheel Belt)	—	QMA4678	Added
M126	Screw $\oplus 26 \times 4$	—	XSN26 + 4	Added

MECHANICAL PARTS LOCATION



Former Type

(ADDITION)



New Type

* 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

Panasonic Tokyo
Matsushita Electric Industrial Co., Ltd.
1-2, 1-chome, Shibakoen, Minato-ku, Tokyo 105 Japan

(ARD, A.H) Printed in Japan